1983-84


IGNITION SWITCH
BLK/RED
BLK/WHT
SPARK PLUGS
BLU
BLU
BLK/WHT
BLK/WHT
SOLENOID VALVE
BLK/WHT
BALL VENT VALVE
BLK/WHT
BLK/WHT
E.S.S. RELAY
FUEL CUT SOLENOID VALVE
BLK
WHT
WHT
IGNITION COIL
WHT
TO INSTRUMENT CLUSTER SYSTEM


IGNITION SWITCH
BLK/YEL
BLK/WHT
FUSE 4
RED/BLU
BLK
FUSE 5A
BLK
AMMETER
WHT/BLK
FUSE 5A
M/T
A/T
BLK/YEL
BLK/YEL
INHIBITOR SWITCH
BLK/YEL
M/T
A/T
BLK/YEL
RED/BLU
CHARGE INDIC.
WHT
BLU
WHT
FUSE LINK
BLK
ALTERNATOR
BLK
BLK/RED
STARTING MOTOR
M
TO ENGINE CONTROLS SYSTEM (1985-86 ONLY)
+
-
BATTERY