MITSUBISHI MOTORS

Body Repair Manual

GALANT '97



Pub. No. PBDE9609

GALANT

BODY REPAIR MANUAL

FOREWORD

This manual has been prepared for the use of all service mechanics engaged in the body repair service. Body dimensions, welded panel replacement procedures, body sealing application instructions, and all the other information required to provide quick and accurate body repair service are contained herein. One especially important point is the welding method. All of the vehicle's original strength and durability can be maintained by following the welding procedures contained in this manual.
Note that, in order to maximize the efficiency of the repair work, first, both the extent of the damage and the replacement parts that are needed must be calculated accurately, and then the actual work must be performed accurately and efficiently.
The publications shown on the following page are also available, and should be used in conjunction with this manual.
Mitsubishi Motors Corporation reserves the right to make changes in design and specifications and/or to make additions to or improvements in its products without imposing any obligation upon itself to install them on its products previously manufactured.

GROUP INDEX

GENERAL 0
BODY CONSTRUCTION 1
BODY DIMENSIONS 2
WELDED PANEL REPLACEMENT 3
CORROSION PROTECTION 4
SYNTHETIC-RESIN PARTS 5
BODY COLOUR 6
WIRING AND PIPING DIAGRAM 7
REFERENCE MATERIAL 8

MITSUBISHI MOTORS CORPORATION

© Mitsubishi Motors Corporation Dec. 1996

RELATED PUBLICATIONS

- TECHNICAL INFORMATION MANUAL
  Pub. No. PYDE9604 [for Europe]
  Pub. No. PYDE9605 [for General Export]
- WORKSHOP MANUAL
  CHASSIS GROUP
  Pub. No. PWDE9611 [for Europe]
  Pub. No. PWDE9617 [for General Export]
  ENGINE GROUP
  Pub. No. PWEE□□□□ (Looseleaf edition)
  ELECTRICAL WIRING
  Pub. No. PHDE9608 [for Europe]
  Pub. No. PHDE9614 [for General Export]
- PARTS CATALOGUE
  B608S107A□ Sedan [for Europe]
  B608T507A□ Wagon [for Europe]
  B808S107A [for General Export]
- BODY REPAIR MANUAL
  Pub. No. PBAE9216 (PASSENGER CARS & LIGHT COMMERCIAL VEHICLES)

MANUAL DESCRIPTION

CONTENTS

The first page of this manual contains a table of contents which lists the title and number of each group.

TEXT

The vehicles to which the information in the text pertains are generally designated according to their body classification. In some cases, other limiting designations such as name, type of drive system, etc., are given. If there are no such limiting designations, the information can be assumed to cover all models.

PAGE NUMBERS

All pages are numbered consecutively within each group. The page numbers can be found on the upper left or right of each page.

SECTION TITLES

The section titles can be found at the upper centre of each page.

NOTE
"GCC" indicates a classification within the models for General Export category: models for countries that are member of the Gulf Cooperation Council.