

[\[Previous\]](#) [\[Next\]](#)

DTC Index

note	The details of time display are as follows • CRNT: A malfunction is detected now • PAST: A malfunction was detected in the past
-------------	---

Self diagnostic result

×:Applicable

M.U.T.-III SE display	Fail-safe	Freeze Frame Data	Reference
B2C20-12: Starter control relay	—	—	DTC Description 
B2C20-14: Starter control relay	—	—	DTC Description 
B2C20-23: Starter control relay	—	—	DTC Description 
B2C20-24: Starter control relay	—	—	DTC Description 
B2C40-04: Power window main switch	—	—	DTC Description 
B2C41-04: Power window motor FL	—	—	DTC Description 
B2C95-01: Combination switch	×	—	DTC Description 
B2C95-64: Combination switch	×	—	DTC Description 
B2C96-49: Light sensor	×	—	DTC Description 
B2CB5-64: Rear wiper	×	—	DTC Description 
B2CCF-04: Passenger door mirror control module	—	—	DTC Description 
B2F06-11: Power liftgate/trunk opener switch	—	—	DTC Description 
B2F06-15: Power liftgate/trunk opener switch	—	—	DTC Description 
B2F60-55: Seat belt buckle switch (driver side)	—	—	DTC Description 
B2F70-01: Stop light	—	—	DTC Description 
B2F70-02: Stop light	—	—	DTC Description 
B2F71-23: Stop light	—	—	DTC Description 
B2F71-24: Stop light	—	—	DTC Description 
B2F72-23: Stop light	—	—	DTC Description 
B2F72-24: Stop light	—	—	DTC Description 
B2F98-04: Sunshade motor	—	—	DTC Description 

M.U.T.-III SE display	Fail-safe	Freeze Frame Data	Reference
B2F99-04: Sunroof motor	—	—	DTC Description ➡
B2FAC-12: Accessory relay	—	—	DTC Description ➡
B2FAC-14: Accessory relay	—	—	DTC Description ➡
B2FAE-12: Ignition relay-1	×	—	DTC Description ➡
B2FAE-14: Ignition relay-1	×	—	DTC Description ➡
B2FAF-12: Ignition relay-2	—	—	DTC Description ➡
B2FAF-14: Ignition relay-2	—	—	DTC Description ➡
B2FB0-12: Ignition relay-3	—	—	DTC Description ➡
B2FB0-14: Ignition relay-3	—	—	DTC Description ➡
C1700-54: Control unit	—	—	DTC Description ➡
C1700-55: Control unit	—	—	DTC Description ➡
C1700-86: Control unit	—	—	DTC Description ➡
C1711-7B: Low tire pressure FL	—	×	DTC Description ➡
C1712-7B: Low tire pressure FR	—	×	DTC Description ➡
C1713-7B: Low tire pressure RR	—	×	DTC Description ➡
C1714-7B: Low tire pressure RL	—	×	DTC Description ➡
C1731-16: Tire pressure sensor FL	—	×	DTC Description ➡
C1731-68: Tire pressure sensor FL	—	×	DTC Description ➡
C1732-16: Tire pressure sensor FR	—	×	DTC Description ➡
C1732-68: Tire pressure sensor FR	—	×	DTC Description ➡
C1733-16: Tire pressure sensor RR	—	×	DTC Description ➡
C1733-68: Tire pressure sensor RR	—	×	DTC Description ➡
C1734-16: Tire pressure sensor RL	—	×	DTC Description ➡
C1734-68: Tire pressure sensor RL	—	×	DTC Description ➡
C1741-21: Tire pressure sensor no data FL	—	×	DTC Description ➡
C1742-21: Tire pressure sensor no data FR	—	×	DTC Description ➡
C1743-21: Tire pressure sensor no data RR	—	×	DTC Description ➡
C1744-21: Tire pressure sensor no data RL	—	×	DTC Description ➡

M.U.T.-III SE display	Fail-safe	Freeze Frame Data	Reference
U1C01-08: LIN communication	—	×	DTC Description 
U1C02-08: LIN communication	—	×	DTC Description 

Network-DTC

×:Applicable

M.U.T.-III SE display	Fail-safe	Freeze Frame Data	Reference
U0073-00: Control module comm Bus A Off	—	—	DTC Description 
U0075-00: Control module comm Bus C Off	—	—	DTC Description 
U20C5-87: CAN comm err (audio amp.)	—	—	DTC Description 
U2140-87: CAN comm err (ECM)	—	—	DTC Description 
U2141-87: CAN comm err (TCM)	—	—	DTC Description 
U2148-87: CAN comm err (brake control unit)	—	—	DTC Description 
U2152-87: CAN comm err (ADAS control unit)	—	—	DTC Description 
U2154-87: CAN comm err (MIU)	—	—	DTC Description 
U216B-87: CAN comm err (front camera)	—	—	DTC Description 
U2175-87: CAN comm err (Multi Around Monitor)	—	—	DTC Description 
U2176-87: CAN comm err (CCM/ST angle sensor)	—	—	DTC Description 
U2218-87: CAN comm err (Keyless operation key)	—	—	DTC Description 
U2250-87: CAN comm err (AIRBAG)	—	—	DTC Description 
U2253-87: CAN comm err (HVAC)	—	—	DTC Description 
U225B-87: CAN comm err (IPDM E/R)	—	—	DTC Description 
U2314-87: CAN comm err (ANC)	—	—	DTC Description 
U234E-87: CAN comm err (combination meter)	—	—	DTC Description 
U2369-87: CAN comm err (PSD/MHB)	—	—	DTC Description 
U237C-87: CAN comm err (seat)	—	—	DTC Description 
U2A06-88: Comm Bus Off V-FD	—	—	DTC Description 

MAC Diagnosis

×:Applicable

M.U.T.-III SE display	Fail-safe	Freeze Frame Data	Reference
U1327-52: MAC key update	—	—	DTC Description 
U1327-54: MAC key update	—	—	DTC Description 
U2140-57: CAN comm err (ECM)	—	—	DTC Description 
U2152-57: CAN comm err (ADAS control unit)	—	—	DTC Description 
U2175-57: CAN comm err (Multi Around Monitor)	—	—	DTC Description 
U2176-57: CAN comm err (CCM/ST angle sensor)	—	—	DTC Description 

cardiagn.com