

MITSUBISHI PAJERO

WORKSHOP MANUAL SUPPLEMENT

FOREWORD

This Workshop Manual contains procedures for removal, disassembly, inspection, adjustment, reassembly and installation, etc. for service mechanics.

Use the following manuals in combination with this manual as required.

TECHNICAL INFORMATION MANUAL
PYJE9002

WORKSHOP MANUAL

ENGINE GROUP

PWEE□□□□
(Looseleaf edition)

CHASSIS GROUP

PWJE9086
(Looseleaf edition)

ELECTRICAL WIRING

PHJE9026
(Looseleaf edition)
PHJE9026-D
(Supplement)
PHJE9026-E
(Supplement)

PARTS CATALOGUE

B6035606A□

General	00
Engine	11
Fuel	13
Automatic Transmission	23
Rear Axle	27
Service Brakes	35
Body	42
Interior and Supplemental Restraint System (SRS)	52
Chassis Electrical	54

All information, illustrations and product descriptions contained in this manual are current as at the time of publication. We, however, reserve the right to make changes at any time without prior notice or obligation.



MITSUBISHI MOTORS CORPORATION

NOTES