

mitsubishi PAJERO

WORKSHOP MANUAL SUPPLEMENT

FOREWORD

This Workshop Manual contains procedures for removal, disassembly, inspection, adjustment, reassembly and installation, etc. for service mechanics.

Use the following manuals in combination with this manual as required.

TECHNICAL INFORMATION MANUAL PYJE9002

WORKSHOP MANUAL ENGINE GROUP

PWEE□□□□
(Looseleaf edition)

CHASSIS GROUP

PWJE9086
(Looseleaf edition)
PWJE9086-G
(Supplement)

ELECTRICAL WIRING

PHJE9026
(Looseleaf edition)
PHJE9026-D
(Supplement)
PHJE9026-E
(Supplement)
PHJE9026-F
(Supplement)

PARTS CATALOGUE

B6035607A□

All information, illustrations and product descriptions contained in this manual are current as at the time of publication. We, however, reserve the right to make changes at any time without prior notice or obligation.

General	00
Fuel	13
Intake and Exhaust.....	15
Service Brakes	35
Interior	52A
Supplemental Restraint System (SRS)	52B
Chassis Electrical	54

NOTES