

---

# HOW TO READ THE WIRING DIAGRAMS

## CONTENTS

MODELS .....	2	ABBREVIATION SYMBOLS .....	2
--------------	---	----------------------------	---

---

## 1-2 HOW TO READ THE WIRING DIAGRAMS - Models/Abbreviation Symbols

---

### MODELS

#### <2-DOOR MODELS>

Model code		Engine model	Transmission model	Fuel supply system
V24W	NDGL6Y	4D56 (2,477 mL) with turbo-charger and inter-cooler	V5MT1 <5M/T>	Injection
	GNDGL6Y			

#### <4-DOOR MODELS>

Model code		Engine model	Transmission model	Fuel supply system
V44W	NDGL6Y	4D56 (2,477 mL) with turbo-charger and inter-cooler	V5MT1 <5M/T>	Injection
	GNDGL6Y			

### ABBREVIATION SYMBOLS

Abbreviation symbols	Meaning
VG	Variable geometry
VG T	Variable geometry turbocharger