

MITSUBISHI SIGMA

WORKSHOP MANUAL ELECTRICAL WIRING

FILING INSTRUCTION

Please keep these manual pages in the binder which is keeping the manual PHGE9036.

File these pages according to the signs "ADDED" and "REVISED" on the "List of effective pages" which are interpreted below.

ADDED: File the pages with this sign additionally in your manual.

REVISED: Replace the existing pages with the corresponding pages with this sign.

Missing sheets will be supplied upon request.

Group/ Page	Revision code	Date	Remarks	Group/ Page	Revision code	Date	Remarks
LIST OF EFFECTIVE PAGES				6		Nov. 1990	
1	A	Apr. 1991	REVISED	7	A	Apr. 1991	REVISED
2	A	Apr. 1991	ADDED	7-1	A	Apr. 1991	ADDED
FOREWORD				8 thru 9		Nov. 1990	
	A	Apr. 1991	REVISED	10 thru 11	A	Apr. 1991	REVISED
HOW TO USE THIS MANUAL				12 thru 14		Nov. 1990	
		Nov. 1990		15 thru 16	A	Apr. 1991	REVISED
1-HOW TO READ THE WIRING DIAGRAMS				16-1	A	Apr. 1991	ADDED
1 thru 8		Nov. 1990		17 thru 21		Nov. 1990	
9	A	Apr. 1991	REVISED	4-CIRCUIT DIAGRAM			
10		Nov. 1990		1 thru 2	A	Apr. 1991	REVISED
2-WIRING HARNESS CONFIGURATION DIAGRAMS				3		Nov. 1990	
1	A	Apr. 1991	REVISED	4 thru 7	A	Apr. 1991	REVISED
2 thru 3		Nov. 1990		8 thru 9		Nov. 1990	
4 thru 5	A	Apr. 1991	REVISED	10 thru 13	A	Apr. 1991	REVISED
6 thru 7		Nov. 1990		14 thru 15		Nov. 1990	
8 thru 9	A	Apr. 1991	REVISED	16 thru 18	A	Apr. 1991	REVISED
10 thru 11		Nov. 1990		19		Nov. 1990	
12 thru 13	A	Apr. 1991	REVISED	20 thru 21	A	Apr. 1991	REVISED
14 thru 19		Nov. 1990		22 thru 23		Nov. 1990	
20	A	Apr. 1991	REVISED	24 thru 26	A	Apr. 1991	REVISED
21		Nov. 1990		27		Nov. 1990	
22	A	Apr. 1991	REVISED	28 thru 32	A	Apr. 1991	REVISED
23		Nov. 1990		33 thru 36		Nov. 1990	
23-1 thru 23-4	A	Apr. 1991	ADDED	37 thru 39	A	Apr. 1991	REVISED
24	A	Apr. 1991	REVISED	40 thru 42		Nov. 1990	
25		Nov. 1990		43 thru 44	A	Apr. 1991	REVISED
26 thru 27	A	Apr. 1991	REVISED	45		Nov. 1990	
27-1 thru 27-4	A	Apr. 1991	ADDED	46	A	Apr. 1991	REVISED
28	A	Apr. 1991	REVISED	47 thru 49		Nov. 1990	
29		Nov. 1990		50 thru 51	A	Apr. 1991	REVISED
30 thru 31	A	Apr. 1991	REVISED	52 thru 55		Nov. 1990	
32 thru 39		Nov. 1990		56	A	Apr. 1991	REVISED
3-SINGLE PART INSTALLATION POSITION				57 thru 58		Nov. 1990	
1 thru 2	A	Apr. 1991	REVISED	59	A	Apr. 1991	REVISED
3		Nov. 1990		60 thru 63		Nov. 1990	
4 thru 5	A	Apr. 1991	REVISED	64	A	Apr. 1991	REVISED
				65		Nov. 1990	

LIST OF EFFECTIVE PAGES

2

Group/ Page	Revision code	Date	Remarks	Group/ Page	Revision code	Date	Remarks
66	A	Apr. 1991	REVISED	199	A	Apr. 1991	REVISED
67		Nov. 1990		200 thru 206		Nov. 1990	
68	A	Apr. 1991	REVISED	207	A	Apr. 1991	REVISED
69		Nov. 1990		208 thru 212		Nov. 1990	
70 thru 71	A	Apr. 1991	REVISED	213	A	Apr. 1991	REVISED
72 thru 73		Nov. 1990		214 thru 219		Nov. 1990	
74 thru 75	A	Apr. 1991	REVISED	220 thru 221	A	Apr. 1991	REVISED
76 thru 87		Nov. 1990		222 thru 226		Nov. 1990	
88	A	Apr. 1991	REVISED	227 thru 228	A	Apr. 1991	REVISED
89		Nov. 1990		229 thru 233		Nov. 1990	
90 thru 91	A	Apr. 1991	REVISED	234	A	Apr. 1991	REVISED
92		Nov. 1990		235		Nov. 1990	
93 thru 94	A	Apr. 1991	REVISED	236 thru 238	A	Apr. 1991	REVISED
95 thru 108		Nov. 1990		239		Nov. 1990	
109-1	A	Apr. 1991	ADDED	240	A	Apr. 1991	REVISED
109-1	A	Apr. 1991	REVISED	241		Nov. 1990	
110 thru 112		Nov. 1990		242 thru 244	A	Apr. 1991	REVISED
113	A	Apr. 1991	REVISED	245 thru 261		Nov. 1990	
114 thru 115		Nov. 1990		262	A	Apr. 1991	REVISED
116 thru 118	A	Apr. 1991	REVISED	263		Nov. 1990	
119 thru 121		Nov. 1990		263-1 thru 263-2	A	Apr. 1991	ADDED
121-1 thru 121-4	A	Apr. 1991	ADDED	264	A	Apr. 1991	REVISED
122 thru 123		Nov. 1990		265 thru 267	A	Apr. 1991	ADDED
124 thru 125	A	Apr. 1991	REVISED				
126 thru 171		Nov. 1990					
172	A	Apr. 1991	REVISED				
173		Nov. 1990					
173-1 thru 173-2	A	Apr. 1991	ADDED				
174		Nov. 1990					
175 thru 176	A	Apr. 1991	REVISED				
177 thru 183		Nov. 1990					
184	A	Apr. 1991	REVISED				
185		Nov. 1990					
185-1 thru 185-2	A	Apr. 1991	ADDED				
186	A	Apr. 1991	REVISED				
187		Nov. 1990					
188 thru 197	A	Apr. 1991	REVISED				
198		Nov. 1990					

RJAK104006-112
RJAK012005-340

MITSUBISHI SIGMA

ELECTRICAL WIRING

GROUP INDEX

FOREWORD

This Electrical Wiring Manual contains information necessary for inspection and servicing of electrical wiring in the Mitsubishi SIGMA edited in the form of wiring harness configuration diagrams and function-separated circuit diagrams.

It is recommended that all service mechanics engaged in the servicing of the vehicle refer to the following publications as well as this manual.

TECHNICAL INFORMATION MANUAL

PYSE9008

PYGE9101

WORKSHOP MANUAL

PWGE9004

(Loose-leaf edition)

WORKSHOP MANUAL

Engine Group

PWEE□□□□

(Loose-leaf edition)

PARTS CATALOGUE

B608A100A□

All information, illustrations and product descriptions contained in this manual are current as of time of publication. We, however, reserve the right to make changes at any time without prior notice or obligation.

HOW TO READ THE **1**
WIRING DIAGRAMS

WIRING HARNESS **2**
CONFIGURATION DIAGRAMS

SINGLE PART INSTALLATION **3**
POSITION

CIRCUIT DIAGRAM **4**



HOW TO USE THIS MANUAL

CONTENTS

The preceding page contains GROUP INDEX which lists the group title and group number.

PAGE NUMBERS

All page numbers consist of two sets of digits separated by a dash. The digits preceding the dash identify the number of the group. The digits following the dash represent the consecutive page number within the group. The page numbers can be found on the top left or right of each page.

OPERATION AND TROUBLESHOOTING HINTS

In the GROUP 4 circuit diagrams, the operation and troubleshooting hints are given on the previous page or following page for each circuit where necessary.