

CLUTCH

CONTENTS

GENERAL INFORMATION

SERVICE SPECIFICATIONS

LUBRICANTS

ON-VEHICLE SERVICE

CLUTCH PEDAL CHECK AND ADJUSTMENT

BLEEDING

CLUTCH PEDAL

REMOVAL AND INSTALLATION

INSPECTION

CLUTCH DISC

REMOVAL AND INSTALLATION

SERVICE POINTS OF REMOVAL

SERVICE POINT OF INSTALLATION

INSPECTION

CLUTCH CONTROL

REMOVAL AND INSTALLATION

REMOVAL SERVICE POINT

INSTALLATION SERVICE POINT

INSPECTION

CLUTCH MASTER CYLINDER

DISASSEMBLY AND REASSEMBLY

INSPECTION

CLUTCH RELEASE CYLINDER

DISASSEMBLY AND REASSEMBLY

REMOVAL SERVICE POINT

INSTALLATION SERVICE POINT

INSPECTION
