

FRONT SUSPENSION

CONTENTS

GENERAL INFORMATION

COIL SPRINGS

SHOCK ABSORBER

CONSTRUCTION DIAGRAM

SERVICE SPECIFICATIONS

SPECIAL TOOLS

ON-VEHICLE SERVICE

FRONT WHEEL ALIGNMENT CHECK AND
ADJUSTMENT

STRUT ASSEMBLY

REMOVAL AND INSTALLATION

REMOVAL SERVICE POINT

INSPECTION

STRUT ASSEMBLY

DISASSEMBLY AND REASSEMBLY

DISASSEMBLY SERVICE POINTS

REASSEMBLY SERVICE POINTS

LOWER ARM

REMOVAL AND INSTALLATION

REMOVAL SERVICE POINTS

INSTALLATION SERVICE POINTS

INSPECTION

BALL JOINT DUST COVER REPLACEMENT

STABILISER BAR

REMOVAL AND INSTALLATION

INSTALLATION SERVICE POINT

INSPECTION

BALL JOINT DUST COVER REPLACEMENT
