

27 REAR AXLE <SEDAN>

CONTENTS

GENERAL INFORMATION

SECTIONAL VIEW

SERVICE SPECIFICATIONS

SPECIAL TOOLS

ON-VEHICLE SERVICE

HUB AXIAL PLAY CHECK

REAR HUB ROTARY-SLIDING RESISTANCE
CHECK

HUB BOLT REPLACEMENT

REAR HUB ASSEMBLY

REMOVAL AND INSTALLATION

REMOVAL SERVICE POINTS

INSTALLATION SERVICE POINT

INSPECTION

KNUCKLE

REMOVAL AND INSTALLATION

REMOVAL SERVICE POINT
