

34 REAR SUSPENSION <SEDAN>

CONTENTS

GENERAL INFORMATION

- COIL SPRING
- SHOCK ABSORBER
- CONSTRUCTION DIAGRAM

SERVICE SPECIFICATIONS

SPECIAL TOOLS

ON-VEHICLE SERVICE

- REAR WHEEL ALIGNMENT CHECK AND ADJUSTMENT

REAR SUSPENSION ASSEMBLY

- REMOVAL AND INSTALLATION
- REMOVAL SERVICE POINT
- INSPECTION

UPPER ARM ASSEMBLY

- REMOVAL AND INSTALLATION
- INSTALLATION SERVICE POINT
- INSPECTION

TRAILING ARM ASSEMBLY

- REMOVAL AND INSTALLATION

INSPECTION

LOWER ARM AND TOE CONTROL ARM ASSEMBLIES

- REMOVAL AND INSTALLATION
- REMOVAL SERVICE POINTS
- INSPECTION
- BALL JOINT DUST COVER REPLACEMENT

SHOCK ABSORBER ASSEMBLY

- REMOVAL AND INSTALLATION
- INSPECTION
- DISASSEMBLY AND REASSEMBLY
- DISASSEMBLY SERVICE POINT
- REASSEMBLY SERVICE POINTS

STABILIZER BAR

- REMOVAL AND INSTALLATION
- INSTALLATION SERVICE POINTS
- INSPECTION
- BALL JOINT DUST COVER REPLACEMENT