

# 35B ANTI-LOCK BRAKING SYSTEM (ABS)

## CONTENTS

### GENERAL INFORMATION

CONSTRUCTION DIAGRAM

### SERVICE SPECIFICATIONS

#### SEALANT

#### SPECIAL TOOLS

#### TROUBLESHOOTING

DIAGNOSIS FUNCTION

ERASING DIAGNOSIS CODES

INSPECTION CHART FOR DIAGNOSIS CODES

ABS WARNING LIGHT INSPECTION

### ACTUATOR TEST REFERENCE TABLE

CHECK AT THE ABS-ECU

### ON-VEHICLE SERVICE

BLEEDING

ABS OPERATION CHECK

### MASTER CYLINDER AND BRAKE BOOSTER

#### HYDRAULIC UNIT

INSTALLATION SERVICE POINT

#### WHEEL SPEED SENSOR

Refer to GROUP 35 for the following items.

#### BRAKE PEDAL

#### FRONT DISC BRAKE

#### LUBRICANTS

#### ON-VEHICLE SERVICE

Brake Booster Operating Test

Brake Fluid Level Sensor Check

Check Valve Operation Check

Front Brake Disc Run-out Check

Front Brake Disc Run-out Correction

Front Brake Disc Thickness Check

Front Disc Brake Pad Check and Replacement

Front Disc Brake Rotor Inspection

Proportioning Valve Function Test

Rear Brake Disc Run-out Check

Rear Brake Disc Run-out Correction

Rear Brake Disc Thickness Check

Rear Disc Brake Pad Check and Replacement

#### REAR DISC BRAKE