

# 42 BODY

## CONTENTS

### SPECIAL TOOLS

#### HOOD

REMOVAL AND INSTALLATION

INSTALLATION SERVICE POINTS

#### TRUNK LID

REMOVAL AND INSTALLATION

REMOVAL SERVICE POINTS

INSTALLATION SERVICE POINTS

INSPECTION

#### TAILGATE

REMOVAL AND INSTALLATION

REMOVAL SERVICE POINTS

INSTALLATION SERVICE POINTS

#### FENDER

REMOVAL AND INSTALLATION

#### FUEL FILLER DOOR

REMOVAL AND INSTALLATION

INSPECTION

#### WINDSHIELD AND WINDOW GLASS

##### WINDOW GLASS

GENERAL

##### WINDSHIELD

REMOVAL AND INSTALLATION

REMOVAL SERVICE POINTS

INSTALLATION SERVICE POINTS

##### REAR WINDOW GLASS

REMOVAL AND INSTALLATION

INSTALLATION SERVICE POINTS

#### TAILGATE WINDOW GLASS

REMOVAL AND INSTALLATION

REMOVAL SERVICE POINTS

INSTALLATION SERVICE POINTS

#### REAR QUARTER WINDOW GLASS

REMOVAL AND INSTALLATION

#### DOOR ASSEMBLY

REMOVAL AND INSTALLATION

INSTALLATION SERVICE POINTS

INSPECTION

#### DOOR TRIM AND WATERPROOF FILM

#### DOOR GLASS AND REGULATOR

REMOVAL AND INSTALLATION

INSTALLATION SERVICE POINTS

INSPECTION

#### ON-VEHICLE SERVICE

DOOR FIT ADJUSTMENT

DOOR GLASS ADJUSTMENT

DOOR GLASS ADJUSTMENTS

FRONT DOOR

REAR DOOR

CIRCUIT BREAKER (INCORPORATED IN THE  
POWER WINDOW MOTOR) INSPECTION

#### DOOR HANDLE AND LATCH

REMOVAL AND INSTALLATION

INSPECTION

**ON-VEHICLE SERVICE**

INSIDE HANDLE PLAY ADJUSTMENT

OUTSIDE HANDLE PLAY CHECK

**DOOR BELT LINE MOULDING AND DOOR  
OPENING WEATHERSTRIP**

REMOVAL AND INSTALLATION

REMOVAL SERVICE POINTS

INSTALLATION SERVICE POINTS

**SUNROOF**

**SERVICE SPECIFICATIONS**

**TROUBLESHOOTING**

CHECKING THE SUNROOF ECU TERMINALS

**ON-VEHICLE SERVICE**

WATER TEST

SUNROOF FIT ADJUSTMENT

**SUNROOF**

REMOVAL AND INSTALLATION

REMOVAL SERVICE POINTS

INSTALLATION SERVICE POINTS

INSPECTION

DISASSEMBLY AND REASSEMBLY