

51 EXTERIOR

CONTENTS

SERVICE SPECIFICATION	REMOVAL AND INSTALLATION
SEALANT AND ADHESIVE	REMOVAL SERVICE POINTS
SPECIAL TOOLS	INSTALLATION SERVICE POINTS
FRONT BUMPER < MAGNA >	WINDSHIELD WIPER AND WASHER
REMOVAL AND INSTALLATION	REMOVAL AND INSTALLATION
DISASSEMBLY AND REASSEMBLY	REAR WIPER AND WASHER
FRONT BUMPER < VERADA >	REMOVAL AND INSTALLATION
REMOVAL AND INSTALLATION	INSTALLATION SERVICE POINTS
DISASSEMBLY AND REASSEMBLY	INSTALLATION SERVICE POINT
REAR BUMPER < MAGNA SEDAN >	INSPECTION
REMOVAL AND INSTALLATION	DOOR MIRROR
REAR BUMPER < VERADA SEDAN >	REMOVAL AND INSTALLATION
REMOVAL AND INSTALLATION	INSPECTION
REAR BUMPER < WAGON >	ROOF RACK
REMOVAL AND INSTALLATION	REMOVAL AND INSTALLATION
GRILLES AND GARNISHES	VR-X BODY KIT FRONT AND SIDE
REMOVAL AND INSTALLATION	REMOVAL AND INSTALLATION
REMOVAL SERVICE POINT	VR-X BODY KIT REAR
MOULDINGS	REMOVAL AND INSTALLATION
REMOVAL AND INSTALLATION	INSTALLATION SERVICE POINT
AERO PARTS	

WARNINGS REGARDING SERVICING OF SUPPLEMENTAL RESTRAINT SYSTEM (SRS) EQUIPPED VEHICLES

WARNING!

- (1) Improper service or maintenance of any component of the SRS, or any SRS-related component, can lead to personal injury or death to service personnel (from inadvertent firing of the air bag) or to the driver and passenger (from rendering the SRS inoperative).
- (2) If it is possible that the SRS components are subjected to heat over 93°C in baking or drying after painting, remove the SRS components (air bag module and SRS-ECU) beforehand.
- (3) Service or maintenance of any SRS component or SRS-related component must be performed only at an authorised MITSUBISHI dealer.
- (4) MITSUBISHI dealer personnel must thoroughly review this manual, and especially its GROUP 52B – Supplemental Restraint System (SRS) and GROUP 00 – Maintenance Service before beginning any service or maintenance of any component of the SRS or any SRS-related component.

NOTE

Section titles with the asterisk (*) in the table of contents in each group indicate operations requiring warnings.