

# 54C CIRCUIT DIAGRAMS

## CONTENTS

JUNCTION BLOCK (J/B)

CENTRALISED JUNCTION

FUSIBLE LINK (Relay box in engine compartment)

DEDICATED FUSE (Relay box and fuse box)

MULTI-PURPOSE FUSE (In junction block)

CENTRALISED RELAY (Relay box in engine compartment)

POWER DISTRIBUTION SYSTEM

STARTING SYSTEM

IGNITION SYSTEM

CHARGING SYSTEM

MPI SYSTEM <Manual Transmission Vehicles>

MPI SYSTEM <Automatic Transmission Vehicles>

COOLING SYSTEM < MAGNA & SPORTS >

COOLING SYSTEM < VERADA >

ELC 4-SPEED AUTOMATIC TRANSMISSION

ELC 4-SPEED AUTOMATIC TRANSMISSION < VERADA >

ELC 5-SPEED AUTOMATIC TRANSMISSION < SPORTS >

HEADLAMP < MAGNA >

HEADLAMP < VERADA >

TAIL LAMP, POSITION LAMP AND LICENCE PLATE LAMP < WAGON >

FOG LAMP < VERADA AND SPORTS >

ROOM LAMP, PERSONAL LAMP AND FOOT LAMP < SEDAN >

ROOM LAMP, PERSONAL LAMP AND FOOT LAMP < WAGON >

GLOVE COMPARTMENT LAMP AND TRUNK LAMP

DOOR LAMP AND FOOT LAMP

EC MIRROR

IGNITION KEY CYLINDER LAMP

STOP LAMP < SEDAN >

STOP LAMP < WAGON >

STOP LAMP < SPORTS >

TURN SIGNAL AND HAZARD LAMP < SEDAN >

TURN SIGNAL AND HAZARD LAMP < WAGON >

BACKUP LAMP < SEDAN >

BACKUP LAMP < WAGON >

HORN

METER < Standard Meter >

METER < High Contrast Meter >

CENTRE MESSAGE DISPLAY

OIL PRESSURE WARNING LAMP

FUEL WARNING LAMP

BRAKE WARNING LAMP

SEAT BELT WARNING LAMP

DOOR AJAR WARNING LAMP

POWER WINDOWS

CENTRAL DOOR LOCKING AND KEYLESS ENTRY < ALL MODELS EXCEPT VERADA Xi >

CENTRAL DOOR LOCKING AND KEYLESS ENTRY <VERADA Xi ONLY>  
TRUNK LID/FUEL TANK DOOR OPENER <ALL MODELS EXCEPT VERADA Xi>  
TRUNK LID/FUEL TANK DOOR OPENER <VERADA Xi ONLY>  
MANUAL AIR CONDITIONING  
FULL AUTOMATIC AIR CONDITIONING  
WINDSHIELD WIPER/WASHER <FRONT>  
WINDSHIELD WIPER/WASHER <REAR>  
DEFOGGER <MAGNA>  
DEFOGGER <VERADA>  
REMOTE CONTROL MIRROR  
CLOCK <VERADA Xi ONLY>  
CIGARETTE LIGHTER AND ASHTRAY LAMP  
PHONE CONNECTION

AUDIO <4 SPEAKER SYSTEM>  
AUDIO <6 & 8 SPEAKER SYSTEM>  
ANTI-SKID BRAKING SYSTEM (ABS) <Without Traction Control>  
ANTI-SKID BRAKING SYSTEM (ABS) <With Traction Control>  
TRACTION CONTROL SYSTEM  
CRUISE CONTROL  
SUPPLEMENTAL RESTRAINT SYSTEM (SRS)  
THEFT ALARM  
IMMOBILISATION  
SUNROOF  
POWER SEAT  
LIGHT MONITOR/ALARM BUZZER  
RHEOSTAT