

SPACE RUNNER

WORKSHOP MANUAL SUPPLEMENT

FOREWORD

This manual outlines changes in servicing procedures related to the chassis including vehicle inspections, adjustments, and improvements in the newly equipped models. Use the following manuals in combination with this manual required.

TECHNICAL INFORMATION MANUAL	PYDE9802
WORKSHOP MANUAL	
CHASSIS GROUP	PWDE9803
ENGINE GROUP	PWEE□□□□ (Looseleaf edition)
ELECTRICAL WIRING	PHDE9802
BODY REPAIR MANUAL	PHDE9802-A
PARTS CATALOGUE	PBDE9802
SPACE RUNNER	B608V500A□
SPACE WAGON	B608W500A□

All information, illustrations and product descriptions contained in this manual are current as at the time of publication. We, however, reserve the right to make changes at any time without prior notice or obligation.

General	00
Engine	11
Fuel	13
Engine Cooling	14
Intake and Exhaust	15
Engine Electrical	16
Engine and Emission Control	17
Clutch	21
Automatic Transmission	23
Front Axle	26
Wheel and Tyre	31
Front Suspension	33
Service Brakes	35
Steering	37

 **MITSUBISHI MOTORS CORPORATION**

“GDI” is the trade mark which Mitsubishi Motors Corporation holds.