

SPACE WAGON

WORKSHOP MANUAL SUPPLEMENT

General	00
Fuel	13
Engine Cooling	14
Rear Axle	27
Service Brakes	35
Chassis Electrical	54

FOREWORD

This manual outlines changes in servicing procedures related to the chassis including vehicle inspections, adjustments, and improvements in the newly equipped models. Use the following manuals in combination with this manual required.

TECHNICAL INFORMATION MANUAL	PYDE9802
WORKSHOP MANUAL	
CHASSIS GROUP	
SPACE RUNNER/SPACE WAGON	PWDE9803
SPACE RUNNER	PEDE9803-A
SPACE RUNNER/SPACE WAGON	PWDH9816R-□ (CD-ROM)
ENGINE GROUP	PWEE□□□□ (Looseleaf edition)
ELECTRICAL WIRING	PHDE9802 PHDE9802-A PHDE9802-B
BODY REPAIR MANUAL	PBDE9802
PARTS CATALOGUE	
SPACE RUNNER	B608V500A□
SPACE WAGON	B608W500A□

All information, illustrations and product descriptions contained in this manual are current as at the time of publication. We, however, reserve the right to make changes at any time without prior notice or obligation.



“GDI” is a trade mark which Mitsubishi Motors Corporation holds.

NOTES