

Edition: June 2006
Revision: June 2006
Publication No. SM7E-1C11U0

NISSAN VERSA

MODEL C11 SERIES

QUICK REFERENCE INDEX

A GENERAL INFORMATION	GI General Information
B ENGINE	EM Engine Mechanical
	LU Engine Lubrication System
	CO Engine Cooling System
	EC Engine Control System
	FL Fuel System
	EX Exhaust System
	ACC Accelerator Control System
C TRANSMISSION/ TRANSAXLE	CL Clutch System
	MT Manual Transaxle
	AT Automatic Transaxle
	CVT CVT
D DRIVELINE/AXLE	FAX Front Axle
	RAX Rear Axle
E SUSPENSION	FSU Front Suspension
	RSU Rear Suspension
	WT Road Wheels & Tires
F BRAKES	BR Brake System
	PB Parking Brake System
	BRC Brake Control System
G STEERING	PS Power Steering System
	STC Steering Control System
H RESTRAINTS	SB Seat Belts
	SRS Supplemental Restraint System (SRS)
I BODY	BL Body, Lock & Security System
	GW Glasses, Window System & Mirrors
	RF Roof
	EI Exterior & Interior
	IP Instrument Panel
	SE Seat
J AIR CONDITIONER	MTC Manual Air Conditioner
K ELECTRICAL	SC Starting & Charging System
	LT Lighting System
	DI Driver Information System
	WW Wiper, Washer & Horn
	BCS Body Control System
	LAN LAN System
	AV Audio Visual, Navigation & Telephone System
	ACS Auto Cruise Control System
	PG Power Supply, Ground & Circuit Elements
L MAINTENANCE	MA Maintenance
M INDEX	IDX Alphabetical Index

A
B
C
D
E
F
G
H
I
J
K
L
M

FOREWORD

This manual contains maintenance and repair procedures for the 2007 NISSAN VERSA.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately. Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.



NISSAN NORTH AMERICA, INC.
Technical Publications Department



PLEASE HELP MAKE THIS SERVICE MANUAL BETTER!

Your comments are important to NISSAN and will help us to improve our Service Manuals.
Use this form to report any issues or comments you may have regarding our Service Manuals.
Please print this form and type or write your comments below. Mail or fax to:

Nissan North America, Inc.
Technical Service Information
39001 Sunrise Drive, P.O. Box 9200
Farmington Hills, MI USA 48331
FAX: (248) 488-3910

SERVICE MANUAL: Model: _____ Year: _____

PUBLICATION NO. (Refer to Quick Reference Index): _____

Please describe any Service Manual issues or problems in detail:

Page number(s) _____ *Note: Please include a copy of each page, marked with your comments.*

Are the trouble diagnosis procedures logical and easy to use? (circle your answer) YES NO

If no, what page number(s)? _____ *Note: Please include a copy of each page, marked with your comments.*

Please describe the issue or problem in detail: _____

Is the organization of the manual clear and easy to follow? (circle your answer) YES NO

Please comment: _____

What information should be included in NISSAN Service Manuals to better support you in servicing or repairing customer vehicles?

DATE: _____ YOUR NAME: _____ POSITION: _____

DEALER: _____ DEALER NO.: _____ ADDRESS: _____

CITY: _____ STATE/PROV./COUNTRY: _____ ZIP/POSTAL CODE: _____

QUICK REFERENCE CHART: VERSA

PFP:00000

Engine Tune-Up Data
GENERAL SPECIFICATIONS

ELS00252

Engine type		MR18DE
Cylinder arrangement		In-line 4
Displacement	cm ³ (cu in)	1,797 (109.65)
Bore and stroke	mm (in)	84.0 x 81.1 (3.307 x 3.192)
Valve arrangement		DOHC
Firing order		1-3-4-2
Number of piston rings	Compression	2
	Oil	1
Compression ratio		9.9
Compression pressure kPa (bar, kg/cm ² , psi) / 250 rpm	Standard	1,500 (15.0, 15.3, 217.6)
	Minimum	1,200 (12.0, 12.2, 174)
	Differential limit between cylinders	100 (1.0, 1.0, 15)

DRIVE BELT

Tension of drive belt	Auto adjustment by auto-tensioner
-----------------------	-----------------------------------

SPARK PLUG

Unit: mm (in)

Plug type	Iridium-tipped TYPE
Make	DENSO
Standard type	FXE20HR11
Spark plug gap	Nominal: 1.1 (0.043)

Front Wheel Alignment (Unladen*1)


ELS00253

Camber Degree minute (Decimal degree)	RH	Minimum	- 1° 05' (- 1.08°)
		Nominal	- 0° 20' (- 0.33°)
		Maximum	0° 25' (0.42°)
	LH	Minimum	- 0° 55' (- 0.92°)
		Nominal	- 0° 10' (- 0.17°)
		Maximum	0° 35' (0.58°)
	Left and right difference (RH - LH)	Minimum	-0° 45' (-0.75°) or less
		Nominal	-0° 12' (-0.20°) or less
		Maximum	0° 21' (0.35°) or less
Caster Degree minute (Decimal degree)	RH	Minimum	4° 05' (4.08°)
		Nominal	4° 50' (4.83°)
		Maximum	5° 35' (5.58°)
	LH	Minimum	3° 55' (3.92°)
		Nominal	4° 40' (4.67°)
		Maximum	5° 25' (5.42°)
	Left and right difference (RH - LH)	Minimum	-0° 21' (-0.35°) or less
		Nominal	0° 12' (0.20°) or less
		Maximum	0° 45' (0.75°) or less

QUICK REFERENCE CHART: VERSA

2007

Kingpin inclination Degree minute (Decimal degree)	Minimum	9° 10' (9.17°)
	Nominal	9° 55' (9.92°)
	Maximum	10° 40' (10.67°)



Total toe-in	Distance (A - B)	Minimum	0 mm (0 in)
		Nominal	1 mm (0.04 in)
		Maximum	2 mm (0.08 in)
	Angle (left or right, each side) Degree minute (Degree)	Minimum	0° 0' (0°)
		Nominal	0° 3' (0.05°)
		Maximum	0° 6' (0.10°)


Rear Wheel Alignment (Unladen*)

ELS00254

Camber Degree minute (Decimal degree)		Minimum	– 2° 01' (– 2.02°)
		Nominal	– 1° 31' (– 1.52°)
		Maximum	– 1° 01' (– 1.02°)
Total toe-in	Distance (A - B)	Minimum	1.0 mm (0.039 in)
		Nominal	5.0 mm (0.197 in)
		Maximum	9.0 mm (0.354 in)
	Angle (A - B)	Minimum	0° 3' (0.05°)
		Nominal	0° 14' (0.23°)
		Maximum	0° 24 (0.41°)

Wheelarch Height (Unladen*)

ELIA0085E



Applied model	185/65R15
Front (Hf)	686 mm (26.97 in)
Rear (Hr)	684 mm (27.01 in)

*: Fuel, engine coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

Brake

ELS00256

Front brake	Brake model	CLZ25VA
	Cylinder bore diameter	57.2 mm (2.252 in)
	Pad Length × width × thickness	115.0 mm × 41.0 mm × 9.5 mm (4.528 in × 1.614 in × 0.374 in)
	Rotor outer diameter × thickness	260 mm × 22.0 mm (10.24 in × 0.866 in)
Rear brake	Brake model	LT20D
	Cylinder bore diameter	15.87 mm (0.625 in)
	Lining Length × width × thickness	194.1 mm × 30.0 mm × 4.0 mm (7.642 in × 1.181 in × 0.157 in)
	Drum outer diameter	228.6 mm (9.000 in)
Master cylinder	Cylinder bore diameter	22.22 mm (0.875 in)
Control valve	Valve model	Electric brake force distribution
Brake booster	Booster model	C255
	Diaphragm diameter	255 mm (10.04 in)
Recommended brake fluid		Genuine NISSAN Super Heavy Duty Brake Fluid, or equivalent DOT 3 (US FMVSS No. 116)

Front Brake Repair Limits

Unit: mm (in)

Brake model		CLZ22VA
Brake pad	Standard thickness (new)	9.5 (0.374)
	Repair limit thickness	2.0 (0.079)
Disc rotor	Standard thickness (new)	24.0 (0.945)
	Repair limit thickness	22.0 (0.866)
	Runout limit	0.04 (0.0016)
	Maximum uneven wear (measured at 8 positions)	0.02 mm (0.0008 in) or less

Rear Brake Repair Limits

Unit: mm (in)

Brake model		LT20D
Brake lining	Standard thickness (new)	4.0 (0.157)
	Repair limit thickness	1.5 (0.059)
Drum	Standard inner diameter (new)	228.6 (9.000)
	Repair limit inner diameter	230.0 (9.055)

Brake Pedal

Unit: mm (in)

Brake pedal free height (from dash panel top surface)	A/T, CVT model	172.4 - 182.4 (6.79 - 7.18)
	M/T model	162.3 - 172.3 (6.39 - 6.78)
Brake pedal depressed height [under a force of 490 N (50 kg-f, 110 lb-f) with the engine running]	A/T, CVT model	98 (3.86) or more
	M/T model	90 (3.54) or more
Clearance between brake pedal lever and the threaded end of stop lamp switch		0.74 - 1.96 (0.0291 - 0.0772)
Pedal play		3 - 11 (0.12 - 0.43)

QUICK REFERENCE CHART: VERSA

2007

Refill Capacities

ELS00257

Description		Capacity (Approximate)		
		Liter	US measure	Imp measure
Fuel		50.0	13 1/4 gal	11 gal
Engine oil Drain and refill	With oil filter change	3.9	4 1/8 qt	3 3/8 qt
	Without oil filter change	3.7	3 7/8 qt	3 1/4 qt
Dry engine (engine overhaul)		4.9	5 1/8 qt	4 3/8 qt
Cooling system (with reservoir at max level)		6.8	7 1/4 qt	6 qt
Manual transaxle fluid (MTF)		2.0	4 1/4 pt	3 1/2 pt
Automatic transaxle fluid (ATF)		7.9	8 3/8 qt	7 qt
CVT fluid		8.3	8 3/4 qt	7 1/4 qt
Brake and clutch fluid		—	—	—
Multi-purpose grease		—	—	—
Windshield washer fluid		4.5	4 3/4 qt	4 qt
Air conditioning system refrigerant		0.45 ± 0.05 kg	0.99 ± 0.11 lb	0.99 ± 0.11 lb
Air conditioning system oil	Type 1	120 m ℓ	4.1 fl oz	4.2 fl oz
	Type 2	100 m ℓ	3.4 fl oz	3.5 fl oz