

<SUPPLEMENT-V>

RESTRAINT SYSTEM

SECTION **RS**

MODIFICATION NOTICE:

Air bag system wiring diagram has been changed.







CONTENTS

TROUBLE DIAGNOSES - Supplemental Restraint System (SRS)	5002
Wiring Diagram - SRS -	5002

TROUBLE DIAGNOSES — Supplemental Restraint System (SRS)

Wiring Diagram — SRS —

RS-SRS-01





TROUBLE DIAGNOSES — Supplemental Restraint System (SRS)

Wiring Diagram — SRS — (Cont'd)

RS-SRS-02

- ⬡(DA) : With dual air bag
- ⬡(PT) : With seat belt pre-tensioner
- ⬡(AP) : With seat belt pre-tensioner (Driver and passenger side)



*: This connector is not shown in "HARNES LAYOUT", EL section.