

Publication Number:  
SM11E00-1F15E0E



## MODEL F15 SERIES

## QUICK REFERENCE INDEX

|                                                           |                                              |
|-----------------------------------------------------------|----------------------------------------------|
| <b>A GENERAL INFORMATION</b>                              | GI General Information                       |
| <b>B ENGINE</b>                                           | EM Engine Mechanical                         |
|                                                           | LU Engine Lubrication System                 |
|                                                           | CO Engine Cooling System                     |
|                                                           | EC Engine Control System                     |
|                                                           | FL Fuel System                               |
|                                                           | EX Exhaust System                            |
|                                                           | STR Starting System                          |
|                                                           | ACC Accelerator Control System               |
| <b>D TRANSMISSION &amp; DRIVELINE</b>                     | CL Clutch                                    |
|                                                           | DLN Driveline                                |
|                                                           | TM Transaxle & Transmission                  |
|                                                           | FAX Front Axle                               |
|                                                           | RAX Rear Axle                                |
| <b>E SUSPENSION</b>                                       | FSU Front Suspension                         |
|                                                           | RSU Rear Suspension                          |
|                                                           | WT Road Wheels & Tires                       |
| <b>F BRAKES</b>                                           | BR Brake System                              |
|                                                           | PB Parking Brake System                      |
|                                                           | BRC Brake Control System                     |
| <b>G STEERING</b>                                         | ST Steering System                           |
|                                                           | STC Steering Control System                  |
| <b>H RESTRAINTS</b>                                       | SB Seat Belt                                 |
|                                                           | SR SRS Airbag                                |
|                                                           | SRC SRS Airbag Control System                |
| <b>I VENTILATION, HEATER &amp; AIR CONDITIONER</b>        | VTL Ventilation System                       |
|                                                           | HA Heater & Air Conditioning System          |
|                                                           | HAC Heater & Air Conditioning Control System |
| <b>J BODY INTERIOR</b>                                    | INT Interior                                 |
|                                                           | IP Instrument Panel                          |
|                                                           | SE Seat                                      |
| <b>K BODY EXTERIOR, DOOR, ROOF &amp; VEHICLE SECURITY</b> | DLK Door & Lock                              |
|                                                           | SEC Security Control System                  |
|                                                           | GW Glass & Window System                     |
|                                                           | PWC Power Window Control System              |
| <b>L DRIVER CONTROLS</b>                                  | BRM Body Repair                              |
|                                                           | EXT Exterior                                 |
|                                                           | MIR Mirrors                                  |
|                                                           | EXL Exterior Lighting System                 |
|                                                           | INL Interior Lighting System                 |
|                                                           | WW Wiper & Washer                            |
|                                                           | DEF Defogger                                 |
|                                                           | HRN Horn                                     |
| <b>M ELECTRICAL &amp; POWER CONTROL</b>                   | PWO Power Outlet                             |
|                                                           | BCS Body Control System                      |
|                                                           | LAN LAN System                               |
|                                                           | PCS Power Control System                     |
|                                                           | CHG Charging System                          |
|                                                           | PG Power Supply, Ground & Circuit Elements   |
| <b>N DRIVER INFORMATION &amp; MULTIMEDIA</b>              | MWI Meter, Warning Lamp & Indicator          |
|                                                           | WCS Warning Chime System                     |
|                                                           | AV Audio, Visual & Navigation System         |
| <b>O CRUISE CONTROL</b>                                   | CCS Cruise Control System                    |
|                                                           | DMS Drive Mode System                        |
| <b>P MAINTENANCE</b>                                      | MA Maintenance                               |

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

# FOREWORD

---

This manual contains maintenance and repair procedures for the NISSAN JUKE, model F15 series.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

---

## IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately.

Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.



**NISSAN INTERNATIONAL SA**

Service Engineering Section

Paris, France