

Publication Number:
SM14E00-1J11E0E



MODEL J11
SERIES

QUICK REFERENCE INDEX

A GENERAL INFORMATION	GI General Information
B ENGINE	EM Engine Mechanical
	LU Engine Lubrication System
	CO Engine Cooling System
	EC Engine Control System
	FL Fuel System
	EX Exhaust System
	ACC Accelerator Control System
	STR Starting System
	CL Clutch
	TM Transaxle & Transmission
	DLN Driveline
	FAX Front Axle
	RAX Rear Axle
	FSU Front Suspension
	RSU Rear Suspension
	WT Road Wheels & Tires
	BR Brake System
	PB Parking Brake System
	BRC Brake Control System
	ST Steering System
	STC Steering Control System
	SB Seat Belt
	SBC Seat Belt Control System
	SR SRS Airbag
	SRC SRS Airbag Control System
	VTL Ventilation System
	HA Heater & Air Conditioning System
	HAC Heater & Air Conditioning Control System
	INT Interior
	IP Instrument Panel
	SE Seat
	DLK Door & Lock
	SEC Security Control System
	GW Glass & Window System
	PWC Power Window Control System
	RF Roof
	EXT Exterior
	BRM Body Repair
	MIR Mirrors
	EXL Exterior Lighting System
	INL Interior Lighting System
	WW Wiper & Washer
	DEF Defogger
	HRN Horn
	PWO Power Outlet
	BCS Body Control System
	LAN LAN System
	PCS Power Control System
	CHG Charging System
	PG Power Supply, Ground & Circuit Elements
	MWI Meter, Warning Lamp & Indicators
	WCS Warning Chime System
	SN Sonar System
	AV Audio, Visual & Navigation System
	CCS Cruise Control System
	DAS Driver Assistance System
	DMS Driver Mode System
	MA Maintenance
D TRANSMISSION & DRIVELINE	
E SUSPENSION	
F BRAKES	
G STEERING	
H RESTRAINTS	
I VENTILATION, HEATER & AIR CONDITIONER	
J BODY INTERIOR	
K BODY EXTERIOR, DOOR, ROOF & VEHICLE	
L DRIVER CONTROLS	
M ELECTRICAL & POWER CONTROL	
N DRIVER INFORMATION & MULTIMEDIA	
O CRUISE CONTROL & DRIVER ASSISTANCE	
P MAINTENANCE	

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

FOREWORD

This manual contains maintenance and repair procedures for the NISSAN QASHQAI, model J11 series.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately.

Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by INFINITI must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.



NISSAN INTERNATIONAL SA

Service Engineering Section
Paris, France