

INSTRUMENT PANEL

ABS

X83

02

1016
645
333
645
645
1016
1016
231
1016

103

1016
156
207
205
243
243

199
1016



BP10—RG
80T—OR
96A—MA
64D—BJ
64C—VI
CPG—BA
RPG—VI
8B—BJ
9P—OR

2A—VI

AP10—JA
27A—SA
30A—BA
28A—VE
32B—SA
32A—BA

41A—BJ
LPG—BE


M—NO

NO
4
5
6
2
3
8
9
12
11

14

CY
16
28
30
18
26
21
22
27

24



NO
13
2
6
10
11
12
15

47F—VI
41B—BA

47K—BJ

CANH—BA
CANL—VI


4Z—GR
4Y—VI

250
199

145

225
225

1094
1094




INSTRUMENT PANEL

SSABS


X83

02


1016
645
333
645
645
1016
1016
231
1016







103



1016
156
207
205
243
243



199
1016




M—NO

250
199

145

225
225



3-109