

SECTION **RS**


MODIFICATION NOTICE:

- Air bag system wiring diagram has been changed.

CONTENTS

TROUBLE DIAGNOSES — Supplemental	
Restraint System (SRS)	3002
Schematic	3002
Wiring Diagram — SRS —/LHD Models	3003
Wiring Diagram — SRS —/RHD Models	3004




Schematic



Wiring Diagram — SRS —/LHD Models

LHD MODELS

RS-SRS-01






Refer to last page (Foldout page).

M2, M3

TROUBLE DIAGNOSES — Supplemental Restraint System (SRS)

Wiring Diagram — SRS —/LHD Models (Cont'd)

RS-SRS-02



★: This connector is not shown in "HARNESS LAYOUT", EL section.

Refer to last page (Foldout page).



M20, B19

TROUBLE DIAGNOSES — Supplemental Restraint System (SRS)

Wiring Diagram — SRS —/LHD Models (Cont'd)

LHD MODELS WITH CONSULT-II

RS-SRS-04






TROUBLE DIAGNOSES — Supplemental Restraint System (SRS)

Wiring Diagram — SRS —/LHD Models (Cont'd)

RS-SRS-05

SA : With side air bag system




TROUBLE DIAGNOSES — Supplemental Restraint System (SRS)

Wiring Diagram — SRS —/RHD Models

RHD MODELS

RS-SRS-06



3	4				17	
21	20	15		1	16	2

(M54)
Y




1	2	3	4	5	6			7	8	9	10	11																					
12	13	14	15	16	17	18	19	20	21	22	23	24	(M141)																				
													W																				
															25	26	27	28	29			30	31	32	33								
															34	35	36	37	38	39	40	41	42	43	44	(M142)							
																																BR	
45	46	47	48	49	50			51	52	53	54	55																					
56	57	58	59	60	61	62	63	64	65	66	67	68	(M143)																				
													BR																				

Refer to last page (Foldout page).

(M2) (M3)

Wiring Diagram — SRS —/RHD Models (Cont'd)

RS-SRS-07



Refer to last page (Foldout page).

(M20), (B19)









*: This connector is not shown in "HARNESS LAYOUT", EL section.

TROUBLE DIAGNOSES — Supplemental Restraint System (SRS)

Wiring Diagram — SRS —/RHD Models (Cont'd)

RHD MODELS WITH CONSULT-II

RS-SRS-09



TROUBLE DIAGNOSES — Supplemental Restraint System (SRS)

Wiring Diagram — SRS —/RHD Models (Cont'd)

RS-SRS-10

 : With side air bag system

