





HARNESS REPAIR KIT

WIRING SYSTEM

58.Harness Repair Kit





A: SPECIFICATION

1. ADAPTATION TABLE

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
B3	 <p style="text-align: right;">WI-06229</p>	1, 2, 4, 5	TFA-034
		3	TFA-042
B8	 <p style="text-align: right;">WI-06230</p>	All	TFA-033
B11	 <p style="text-align: right;">WI-06231</p>	All	TFA-036
B12	 <p style="text-align: right;">WI-06232</p>	All	TFA-018





HARNES REPAIR KIT

WIRING SYSTEM

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
B17	 <p style="text-align: right;">WI-06234</p>	All	TFA-019
B18	 <p style="text-align: right;">WI-06235</p>	1, 2 3, 4	TFA-027 TFA-040
B19 (NON-TURBO model)	 <p style="text-align: right;">WI-06237</p>	1, 2 3, 4	TFA-028 TFA-027
B19 (TURBO model)	 <p style="text-align: right;">WI-06236</p>	1, 2 3, 4	TFA-033 TFA-026





HARNESS REPAIR KIT

WIRING SYSTEM

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
B20 (NON-TURBO model)	 <p style="text-align: right;">WI-06240</p>	All	TFA-035
B20 (TURBO model)	 <p style="text-align: right;">WI-06242</p>	All	TFA-041
B21	 <p style="text-align: right;">WI-06244</p>	1 - 8, 10, 14	TFA-036
		9, 11 - 13, 15 - 20	TFA-037
B22	 <p style="text-align: right;">WI-06216</p>	All	TFA-032





HARNESS REPAIR KIT

WIRING SYSTEM

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
B25	 <p style="text-align: right;">WI-06234</p>	All	TFA-019
B54 (NON-TURBO model)	 <p style="text-align: right;">WI-06250</p>	All	TFA-011
B54 (TURBO model)	 <p style="text-align: right;">WI-06251</p>	All	TFA-016
B55 (NON-TURBO model)	 <p style="text-align: right;">WI-06252</p>	All	TFA-011

HARNESS REPAIR KIT

WIRING SYSTEM

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
B55 (TURBO model)	 <p style="text-align: center;">WI-06253</p>	1, 3 - 6, 8, 17	TFA-011
		2, 7, 9 - 16, 18 - 24	TFA-016
B56 (NON-TURBO model)	 <p style="text-align: center;">WI-06254</p>	All	TFA-011
B56 (TURBO model)	 <p style="text-align: center;">WI-06255</p>	1 - 9, 21, 31	TFA-011
		10 - 20, 22 - 30	TFA-016
B127	 <p style="text-align: center;">WI-06220</p>	All	TFA-029

HARNES REPAIR KIT

WIRING SYSTEM

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
B134 (NON-TURBO model)		7, 8, 22, 23, 34, 35	TFA-023
		1 - 6, 9 - 21, 24 - 33	TFA-025
B134 (TURBO model)		1 - 7	TFA-011
		8 - 34	TFA-013
B135 (NON-TURBO model)		1, 2, 9, 21	TFA-023
		3, 6, 7, 12 - 19	TFA-024
		4, 5, 8, 10, 11, 20, 22 - 28	TFA-025
B135 (TURBO model)		1 - 7	TFA-011
		8 - 35	TFA-013





HARNESS REPAIR KIT

WIRING SYSTEM

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
B136 (NON-TURBO model)	<p style="text-align: center;">WI-06265</p>	1 - 4, 7 - 12, 14, 15, 18 - 21, 24	TFA-025
		5, 6, 16, 17, 25, 26	TFA-023
		13, 22, 23	TFA-024
B136 (TURBO model)	<p style="text-align: center;">WI-06267</p>	1 - 6	TFA-011
		7 - 14, 16, 19 - 27, 30 - 33, 35	TFA-013
		15, 17, 18, 28, 29, 34	TFA-014
B137 (NON-TURBO model)	<p style="text-align: center;">WI-06269</p>	1 - 6, 12 - 15, 19, 20	TFA-023
		7 - 11, 16 - 18	TFA-025
B137 (TURBO model)	<p style="text-align: center;">WI-06271</p>	1 - 7	TFA-011
		8 - 31	TFA-013





HARNESS REPAIR KIT

WIRING SYSTEM

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
B279	 <p style="text-align: right;">WI-06275</p>	All	TFA-041
B280	 <p style="text-align: right;">WI-06276</p>	All	TFA-011
B317	 <p style="text-align: right;">WI-06277</p>	All	TFA-032
F3	 <p style="text-align: right;">WI-06211</p>	All	TFA-033





HARNESS REPAIR KIT

WIRING SYSTEM

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
F4	 <p style="text-align: right;">WI-06212</p>	All	TFA-033
F7	 <p style="text-align: right;">WI-06213</p>	All	TFA-029
F19	 <p style="text-align: right;">WI-06211</p>	All	TFA-033
F22	 <p style="text-align: right;">WI-06212</p>	All	TFA-033





HARNESS REPAIR KIT

WIRING SYSTEM

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
F23	 <p style="text-align: right;">WI-06213</p>	All	TFA-029
F25	 <p style="text-align: right;">WI-06214</p>	All	TFA-018
F60	 <p style="text-align: right;">WI-06216</p>	All	TFA-032
F61	 <p style="text-align: right;">WI-06217</p>	1 - 8, 11, 13 - 15	TFA-036
		9, 10, 12, 16 - 20	TFA-037





HARNES REPAIR KIT

WIRING SYSTEM

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
R47	 <p style="text-align: right;">WI-06218</p>	All	TFA-020
R58	 <p style="text-align: right;">WI-06219</p>	All	TFA-032
R59	 <p style="text-align: right;">WI-06220</p>	All	TFA-029
R68	 <p style="text-align: right;">WI-06221</p>	All	TFA-032



HARNESS REPAIR KIT

WIRING SYSTEM

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
R70	 <p style="text-align: right;">WI-04703</p>	All	TFA-012
R79	 <p style="text-align: right;">WI-06223</p>	All	TFA-032
R122	 <p style="text-align: right;">WI-06224</p>	All	TFA-030
R135	 <p style="text-align: right;">WI-06227</p>	All	TFA-032

HARNESS REPAIR KIT

WIRING SYSTEM

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
R143	 <p data-bbox="784 517 878 538">WI-06228</p>	All	TFA-043
R144	 <p data-bbox="784 878 878 900">WI-06220</p>	All	TFA-029