


MAIN RELAY




B61 F44

BATTERY

SBF-5

B47

B100
F2







B62
F45


F61
E2



FUEL INJECTOR



F45



B47

