



TUMBLE GENERATOR
POSITION SENSOR RH



E54

1	2	3
---	---	---

B73



B134

1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	17
18	19	20	21	22	23	24	25	26	27
28	29	30	31	32				33	34