

### **7. Clear Memory Mode**

#### **A: OPERATION**

##### **1. ECM**

For the operation procedure, refer to the “PC application help for Subaru Select Monitor”.

##### **NOTE:**

Initial diagnosis of electronic throttle control is performed after memory clearance. Wait for 10 seconds or more after turning the ignition switch to ON, and then start the engine.

##### **2. BODY INTEGRATED UNIT**

For the operation procedure, refer to the “PC application help for Subaru Select Monitor”.