


4. Schematic



B4M0647A

- ① Hydraulic control unit
- ② Motor
- ③ Motor relay
- ④ Front left solenoid valve
- ⑤ Front right solenoid valve
- ⑥ Rear solenoid valve
- ⑦ Valve relay
- ⑧ AT control module
- ⑨ A.B.S. control module
- ⑩ Warning light

- ⑪ Stop light
- ⑫ Stop light switch
- ⑬ G sensor (AWD MT model)
- ⑭ Ignition switch
- ⑮ Battery
- ⑯ Front left sensor
- ⑰ Front right sensor
- ⑱ Rear left sensor
- ⑲ Rear right sensor
- ⑳ Diagnosis connector