

### **8. Clear Memory Mode**

#### **A: OPERATION**

##### **1. WITHOUT SUBARU SELECT MONITOR**

NOTE:

Use the Subaru Select Monitor for the Clear Memory Mode.

##### **2. WITH SUBARU SELECT MONITOR**

For details concerning DTC clear operation, refer to "Subaru Select Monitor". <Ref. to LAN(diag)-21, CLEAR MEMORY MODE, OPERATION, Subaru Select Monitor.>