

Bulkhead Wiring Harness (In Compartment)

WIRING SYSTEM

56.Bulkhead Wiring Harness (In Compartment)

A: LOCATION

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
B31	12	Yellow	C-1	AB1	Airbag wiring harness
B32	8	★	C-2		Turn signal & hazard unit
B36	28	★	B-2	i1	Instrument panel wiring harness
B37	8	★	C-5	i2	Instrument panel wiring harness (Manual A/C)
B38	20	★	B-5	i3	Instrument panel wiring harness
B40	16	Black	C-2		Data link connector
B41	2	★	B-2		Power window circuit breaker
B47	6	Brown	B-5		Main relay
B52	24	★	C-2		Fuse & relay box (F/B)
B53	20	★	C-3		Joint connector (4AT model)
B54	24	★	C-3		TCM (5AT model)
	35	★	C-3		TCM (4AT model)
B55	24	Gray	C-3		TCM (5AT model)
	35	★	C-3		TCM (4AT model)
B65	4	Black	B-3		Stop light & brake switch
B68	8	★	B-3		Roll connector
B69	4	★	B-3		Parking switch
B70	18	★	B-3		Combination switch
B71	17	★	B-3		
B72	6	★	B-3		Ignition switch
B75	2	Green	C-4	B76	Test mode connector
B76	2	Green	C-4	B75	
B77	7	Green	B-4		Mode actuator
B83	8	★	C-5		Joint connector
B85	2	Black	B-2		Diode (Fog light)
B86	4	★	B-4		Power transistor
B86	4	★	B-4		Blower fan controller (Auto A/C)
B87	2	★	B-5		Blower fan motor
B88	5	★	B-4		Evaporator thermo switch (Manual A/C)
	2	★	B-4		Evaporator thermo switch (Auto A/C)
B90	16	★	B-5	R50	Roof cord
B91	7	Green	B-4		Intake door actuator
B96	8	Black	B-1		Daytime running light control module
B97	20	★	C-1	R1	Rear wiring harness
B98	16	★	B-5	R2	
B106	2	★	B-2		Clutch switch
B107	2	Blue	B-2		Clutch switch

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
B116	12	★	D-4		AT select lever
B122	8	★	C-5		Joint connector (E/G)
B134	34	★	C-4		ECM
B135	35	★	C-4		
B136	35	★	C-4		
B137	31	★	C-4		
B138	8	★	C-5		Joint connector
B152	10	Gray	C-2		Fuse & relay box (F/B)
B158	8	★	C-2		
B159	9	Brown	C-2		
B170	8	★	C-4		CAN joint connector
B177	2	★	B-4		Wiper de-icer
B178	8	Brown	B-2		Instrument panel wiring harness
B179	4	★	B-2		Diode (Headlight)
B180	24	★	C-2		Remote engine start control module
B181	2	★	C-2		Short connector
B182	2	★	C-2		Short connector
B224	2	★	B-4		Key illumination
B225	40	Black	C-2		Fuse (Relay block)
					Mirror heater relay
					Starter relay
					Front fog light relay
					Power window relay
					Blower fan relay
					Daytime running light relay
					Wiper de-icer relay
					Seat heater relay
B226	4	Black	B-2		Inhibitor relay (Turbo-H6 model)
B229	2	Black	B-1		Diode (Parking brake) (Non-turbo model)
B230	4	Black	D-4		Yaw rate sensor (VDC)
B231	4	★	B-4		Steering angle sensor (VDC)
B235	7	Green	B-4		Passenger seat air mix actuator (Auto A/C)
B242	10	★	B-1		Daytime running light control module
B280	30	★	C-3		Body integrated unit
B281	28	★	C-3		
B282	16	★	B-4		Auto A/C control module
B283	20	★	B-4		
B292	3	Black	D-4		ABS G sensor

Bulkhead Wiring Harness (In Compartment)

WIRING SYSTEM

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
B315	6	Black	B-3		Acceleration pedal position sensor
B327	6	Brown	B-5		Oxygen sensor relay (SOHC model)
					Main relay 2 (H6 model)
B350	4	★	B-3		Key warning switch & key lock solenoid
B351	2	Black	B-4		Antenna
B356	4	Black	C-3		BACK-UP LIGHT RELAY (5AT MODEL)
B357	4	Black	C-3		PV-IGN relay (5AT model)
B359	3	Black	D-4		AT G sensor (5AT model)
B362	8	Black	B-5		Relay holder
B365	20	Black	B-3		CAN joint connector
B370	2	Black	C-1		Diode (Engine status)
B373	2	★	B-1		Fuse & relay box (F/B)
B390	7	Green	B-3		Driver seat air mix actuator (Auto A/C)
B404	1	Black	D-4		Parking brake switch
★ : White or natural color					

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
AB1	12	Yellow	C-1	B31	Airbag wiring harness
AB2	4	Yellow	B-4	AB7	Inflator (Driver seat)
AB6	28	Yellow	C-4		Airbag control module
AB9	4	Yellow	B-5	AB10	Inflator (Passenger's seat)

WIRING SYSTEM

