

## 12. Engine Coolant

### A: REPLACEMENT

Refer to "CO" section for engine coolant replacement. <Ref. to CO(H4SO)-13, REPLACEMENT, Engine Coolant.> <Ref. to CO(H4DOTC)-14, REPLACEMENT, Engine Coolant.> <Ref. to CO(H6DO)-12, REPLACEMENT, Engine Coolant.>