

### 14. System Operation Check Mode

#### A: OPERATION

**CAUTION:**

After executing the system operation check mode, execute the Clear Memory Mode. <Ref. to EN(H4SO)(diag)-51, OPERATION, Clear Memory Mode.>

**NOTE:**

For detailed operation procedures, refer to “PC application help for Subaru Select Monitor”.