

25.Crankshaft

A: SPECIFICATION

Refer to “Cylinder Block” for removal and installation procedures of the crankshaft. <Ref. to ME(H6DO)-100, REMOVAL, Cylinder Block.>
<Ref. to ME(H6DO)-106, INSTALLATION, Cylinder Block.>