

## 4. Extension Case

### A: NOTE

For removal, installation and inspection, refer to  
“5AT” or “CVT” section.

5AT model:

<Ref. to 5AT-65, Extension Case.>

CVT model:

<Ref. to CVT-137, Extension Case.>