

### 8. Read Diagnostic Trouble Code (DTC)

#### A: OPERATION

For operation procedures, refer to the “PC application help for Subaru Select Monitor”.

NOTE:

For details concerning DTCs, refer to List of Diagnostic Trouble Codes (DTC). <Ref. to AB(diag)-36, List of Diagnostic Trouble Code (DTC).>