

1. General Description

A: SPECIFICATION

Refer to “Body Repair Manual” for general description of body structure, reference points and reference dimensions.

INSTRUMENTATION/DRIVER INFO



	Page
1. General Description	2
2. Relay and Fuse	4
3. Combination Meter System	5
4. Clock System	16
5. Combination Meter	20
6. Speedometer	26
7. Tachometer	27
8. Fuel Gauge	28
9. ECO Gauge	29
10. Multi Display	30