

General Diagnostic Table

HVAC SYSTEM (HEATER, VENTILATOR AND A/C)

29.General Diagnostic Table

A: INSPECTION

Refer to “Diagnostics with Phenomenon” for HVAC SYSTEM (AUTO A/C) (DIAGNOSTICS). <Ref. to AC(di-ag)-71, INSPECTION, Diagnostics with Phenomenon.>

General Diagnostic Table

HVAC SYSTEM (HEATER, VENTILATOR AND A/C)

HVAC SYSTEM (DIAGNOSTICS)

AC(diag)

	Page
1. Basic Diagnostic Procedure	2
2. General Description	3
3. Electrical Component Location	9
4. Control Module I/O Signal	11
5. Diagnostic Chart for Self-Diagnosis	13
6. Diagnostics for A/C System Malfunction	16
7. Diagnostic Procedure for Sensors	28
8. Subaru Select Monitor	30
9. Read Diagnostic Trouble Code (DTC)	31
10. Clear Memory Mode	32
11. Read Current Data	33
12. Diagnostic Procedure for Subaru Select Monitor Communication	34
13. List of Diagnostic Trouble Code (DTC)	35
14. Diagnostic Procedure with Diagnostic Trouble Code (DTC)	37
15. Diagnostics with Phenomenon	71