


37.Door Switch

A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Remove the door switch.
 - (1) Remove the screws, and pull out the door switch.
 - (2) Disconnect the connector and remove the door switch.



LI-01057

B: INSTALLATION

Install each part in the reverse order of removal.

C: INSPECTION

Refer to DOOR SWITCH CHECK of Interior Light System. <Ref. to LI-15, CHECK DOOR SWITCH., INSPECTION, Interior Light System.>

Door Switch

LIGHTING SYSTEM

WIPER AND WASHER SYSTEMS

WW

	Page
1. General Description	2
2. Wiper and Washer System	7
3. Combination Switch (Wiper)	8
4. Wiper Blade	15
5. Washer Tank and Motor	18
6. Front Wiper Arm	24
7. Front Wiper Motor and Link	26
8. Front Washer Nozzle	32
9. Rear Wiper Arm	36
10. Rear Wiper Motor	38
11. Rear Washer	43