


Electrical Component Location




OCCUPANT DETECTION SYSTEM (DIAGNOSTICS)

4. Electrical Component Location

A: LOCATION



- (1) Occupant detection control module (3) Airbag ON/OFF indicator light (4) Buckle switch (Passenger's seat)
- (2) Occupant detection sensor



SUBARU.