


## 54. Harness Components Location

### A: LOCATION

#### 1. SEDAN MODEL




WI-25606

(1) Front wiring harness	(6) Rear door cord RH	(11) Front door cord LH
(2) Engine wiring harness	(7) Rear wiring harness RH	(12) Transmission cord
(3) Bulkhead wiring harness	(8) Roof cord	(13) Oxygen sensor cord
(4) Instrument panel wiring harness	(9) Trunk lid cord	(14) Rear wiring harness LH
(5) Front door cord RH	(10) Rear door cord LH	(15) Fuel cord

# Harness Components Location

## WIRING SYSTEM

### 2. OUTBACK MODEL



(1) Front wiring harness	(6) Rear door cord RH	(11) Front door cord LH
(2) Engine wiring harness	(7) Rear wiring harness RH	(12) Transmission cord
(3) Bulkhead wiring harness	(8) Roof cord	(13) Oxygen sensor cord
(4) Instrument panel wiring harness	(9) Rear gate cord	(14) Rear wiring harness LH
(5) Front door cord RH	(10) Rear door cord LH	(15) Fuel cord