

### **20. Parking Brake**

#### **A: INSPECTION**

Refer to “PB” section for parking brake inspection.  
<Ref. to PB-16, INSPECTION, Parking Brake Assembly (Rear Disc Brake).>

#### **B: ADJUSTMENT**

Refer to “PB” section for parking brake adjustment.  
<Ref. to PB-17, ADJUSTMENT, Parking Brake Assembly (Rear Disc Brake).>