

General Diagnostic Table

CONTROL SYSTEMS

10.General Diagnostic Table

A: INSPECTION

Symptoms	Possible cause	Corrective action
AT select lever	Starter does not run.	Adjust the select cable and inhibitor switch, or inspect the circuit.
	Back-up light does not illuminate.	Adjust the select cable and inhibitor switch, or inspect the circuit.
	AT shift lock system does not operate normally.	Adjust the select cable and inhibitor switch, or inspect the circuit.
	Manual mode can not be set.	Inspect the mode switch and select lever, or inspect the circuit.
	Up-shift is not engaged at manual mode.	Check the shift-up switch and circuit.
	Down-shift is not engaged at manual mode.	Check the shift-down switch and circuit.
MT gear shift lever (6MT)	Cannot shift into reverse.	Adjust the MT gear select cable.
	Shifted to 6th though it shifted to reverse.	Adjust or replace the MT gear select cable.
	Can shift into reverse when the slider is not pulled up.	Adjust or replace the MT gear select cable.
	Slider cannot be pulled up or sticks in the pulled-up position.	• Check the shift link system of the transmission. • Replace the MT gear shift lever.

CONTINUOUSLY VARIABLE TRANSMISSION

CVT

	Page
1. General Description	2
2. CVTF	35
3. Differential Gear Oil	40
4. AWD ON/OFF Switching Mode	44
5. Road Test	45
6. Stall Test	46
7. Time Lag Test	47
8. Secondary Pressure (Line Pressure) Test	48
9. Transfer Clutch Pressure Test	51
10. Automatic Transmission Assembly	57
11. Transmission Mounting System	85
12. Extension Case Oil Seal	88
13. Differential Side Retainer Oil Seal	90
14. Inhibitor Switch	94
15. Turbine Speed Sensor	101
16. Secondary Speed Sensor	103
17. Primary Speed Sensor	105
18. Secondary Pressure Sensor	108
19. Oil Pan and Strainer	110
20. Control Valve Body	114
21. Transmission Harness	127
22. Transmission Control Module (TCM)	138
23. CVTF Cooler Pipe and Hose	140
24. Air Breather Hose	150
25. Drive Plate	152
26. Torque Converter Assembly	154
27. Preparation for Overhaul	156
28. Extension Case	158
29. Transfer Clutch	162
30. Transfer Driven Gear	176
31. Parking Pawl	179
32. Reduction Driven Gear	181
33. Transmission Control Device	189
34. Transmission Case	195
35. CVTF Filter	206
36. Reduction Drive Gear	207
37. Primary Pulley and Secondary Pulley	211
38. Variator Chain	231
39. Reverse Brake Assembly	232
40. Forward Clutch Assembly	247
41. Drive Pinion Shaft Assembly	266
42. Front Differential Assembly	295
43. Oil Pump Chain	312
44. Oil Pump	321
45. Converter Case	324
46. Diagnostics with Phenomenon	327