

## **Read Diagnostic Trouble Code (DTC)**

CONTINUOUSLY VARIABLE TRANSMISSION (DIAGNOSTICS)

---

### **7. Read Diagnostic Trouble Code (DTC)**

#### **A: OPERATION**

- For detailed operation procedures, refer to “PC application help for Subaru Select Monitor”.
- For details concerning DTC, refer to List of Diagnostic Trouble Code (DTC). <Ref. to CVT(diag)-29, List of Diagnostic Trouble Code (DTC).>