

Read Diagnostic Trouble Code (DTC)

PARKING BRAKE (DIAGNOSTICS)

7. Read Diagnostic Trouble Code (DTC)

A: OPERATION

NOTE:

- For detailed operation procedures, refer to “PC application help for Subaru Select Monitor”.
- For details concerning DTCs, refer to “List of Diagnostic Trouble Code (DTC)”. <Ref. to PB(diag)-34, List of Diagnostic Trouble Code (DTC).>