

## **Read Diagnostic Trouble Code (DTC)**

VEHICLE DYNAMICS CONTROL (VDC) (DIAGNOSTICS)

---

### **7. Read Diagnostic Trouble Code (DTC)**

#### **A: OPERATION**

**NOTE:**

- For detailed operation procedures, refer to “PC application help for Subaru Select Monitor”.
- For details concerning DTCs, refer to “List of Diagnostic Trouble Code (DTC)”. <Ref. to VDC(diag)-34, List of Diagnostic Trouble Code (DTC).>