

1. General Description

A: SPECIFICATION

Refer to “Body Repair Manual” for general description of body structure, reference points and reference dimensions.

INSTRUMENTATION/DRIVER INFO



	Page
1. General Description	2
2. Relay and Fuse	6
3. Combination Meter System	7
4. Clock System	22
5. Combination Meter	26
6. Speedometer	33
7. Tachometer	34
8. Fuel Gauge	35
9. ECO Gauge	36
10. Engine Coolant Temperature Gauge	37
11. Multi Display	38
12. Steering Switch	40