

## 7. Real-time Diagnosis

### A: OPERATION

- 1) Select {Current Data Display & Save} in «Engine Diagnosis» display screen.
- 2) Make sure that normal display is shown when operated as follows:
  - Depress and release the brake pedal. (Stop light switch and brake switch are turned ON.)
  - Turn the “CRUISE” switch to ON.
  - Turn the “CANCEL” switch to ON.
  - Turn the “SET/-” switch to ON.
  - Turn the “RES/+” switch to ON.
  - Depress or release the clutch switch.
  - Place the shift lever in any position other than neutral.

NOTE:

For detailed operation procedures, refer to “PC application help for Subaru Select Monitor”.