


Electrical Component Location

KEYLESS ACCESS WITH PUSH BUTTON START SYSTEM (DIAGNOSTICS)

4. Electrical Component Location

A: LOCATION



SL-01740

Electrical Component Location

KEYLESS ACCESS WITH PUSH BUTTON START SYSTEM (DIAGNOSTICS)

(1) Keyless access CM	(9) Front exterior antenna	(17) TCM
(2) ID code box	(10) Oscillator	(18) Body integrated unit
(3) Mechanical key	(11) Center interior antenna	(19) Receiver
(4) Access key	(12) ECM	(20) Rear interior antenna
(5) Access key warning light	(13) Front interior antenna	(21) Rear exterior antenna
(6) Multi information display	(14) Push button ignition switch	(22) Rear gate opener button
(7) Touch sensor	(15) Steering lock CM	(23) Rear lock button
(8) Front lock button	(16) Access buzzer	