

A2
Engine Room Main Wire
Instrument Panel Wire
D2
D3
Engine Room Main Wire
Roof Wire
A3
Front Door Wire RH
D4
Front Door Wire LH
No. 1 Floor Wire
D1
No. 2 Floor Wire
Instrument Panel Wire Assembly
No. 2 Floor Wire
No. 1 Floor Wire