



* 10:Before May 2014 Production
D8
D9
D17
D16
D13
D29
D14
D30
D39
D7
D12
D18
D24
D6
D5
D37
D21
D20
D23
D22
D26
D2
D3
D4
(*10)
D10
D19
D25
D27
D28
D31
D35
D36
D32
D33
D34

D 2 Light Control Rheostat
D 3 Headlight Leveling Switch
D 4 Luggage Door Opening Switch Assembly
D 5 Main Body ECU
D 6 Main Body ECU
D 7 Combination Meter Assembly
D 8 Junction Connector
D 9 Junction Connector
D 10 DLC3
D 12 Radio Receiver Assembly
D 13 Radio Receiver Assembly
D 14 Radio Receiver Assembly
D 16 Junction Connector
D 17 Junction Connector
D 18 Clock Assembly
D 19 A/C Control Assembly
D 20 A/C Control Assembly
D 21 No. 3 Heater Control Sub-Assembly
D 22 Heater Control Sub-Assembly
D 23 Heater Control Sub-Assembly
D 24 Heater Control Base Sub-Assembly
D 25 Engine Switch
D 26 Indoor Electrical Key Oscillator
D 27 Airbag ECU Assembly
D 28 Shift Lever Assembly
D 29 Option Connector
D 30 Passenger Side Squib Circuit (Instrument Panel Passenger Airbag without Door Assembly)
D 31 Parking Brake Switch Assembly
D 32 Seat Heater Switch LH
D 33 Seat Heater Switch RH
D 34 No. 2 Power Outlet Socket Assembly
D 35 Pattern Select Switch Assembly
D 36 Shift Position Indicator
D 37 Airbag Cut Off Switch Cylinder Sub-Assembly
D 39 Front No. 2 Speaker Assembly RH


D 2
White




D 3
White




D 4
White




D 5
White




D 6
White




D 7
White




D 8
Blue




D 9
Blue




D 10
White




D 12
White




D 13
White




D 14
White




D 16
Black




D 17
Black




D 18
White



D 19
White




D 20
White




D 21
White




D 22
White




D 23
White




D 24
White




D 25
White




D 26
White




D 27
White




D 28
White



D 29
White




D 30
White




D 31
White




D 32
White




D 33
White




D 34
White



D 35
White



D 36
White



D 37
White



D 39
White

